Liberator[™] **Series**

FOLD-ABLE & STOW-ABLE TRUNK LIFTS



Installation is as Easy as 1-2-3!

Freedom Lift's Liberator Series allows your customers to fit the scooter or power wheelchair into the trunk or van with the seat attached or removed. Available in three models, the Liberator products disassemble quickly and easily into separate components for care-free storage.









Liberator™ Features

- Three Models Available | Stow-Able and Fold-Able
- Reliable | Robust welded steel construction.
- **Easy Installation** I The deck base mounts on the inside of the trunk and cargo area. The receiver base mounts on the outside of the vehicle.
- Optional Receiver Base | Mounts to Class I, II or Class III hitch receiver.
- Motorized Lifting Strap
- 250- and 400-pound Lifting Capacities Available
- Hand-held Push Button Controls
- Manual Boom Swing
- Lifting Bracketry | Available for most scooters and power chairs.
- Versatile | The deck base can be mounted on either side of the vehicle.
- Attractive and Durable | Black powder-coated finish
- Fits In or On Most Vehicles | Cars, Vans, SUV's
- Limited Lifetime Warranty | Guarantees customer satisfaction
- **Possible Reimbursement** | Many car companies reimburse all or part of the cost with the purchase of a new vehicle.
- Optional Rechargeable Mobile Power Pack

Liberator Installation

All three Liberator models, the Fold-Able, Stow-Able and Liberator Plus, are easily installed. The Fold-Able Lift provides a simple hinge design to store the lift inside the trunk. The Stow-Able Lift easily disassembles into separate components that can be stored individually. The deck and receiver base options of the Stow-Able Lift gives your customers the choice of permanent mounting within the vehicle or as an extension of a Class II or Class III external hitch receiver. The Liberator-Plus Lift is a reinforced heavy duty lift with a 400 lb. lifting capacity and easily disassembles into separate components that can be stored individually.

Vehicle Specifications

The Liberator Trunk Lifts will fit most vehicles. The Deck Base should be mounted by a qualified installer to avoid damage to the vehicle's components located underneath the mounting surface. When using the Receiver Base, combined scooter and lift weights must not exceed the tongue weight limits of your hitch or vehicle. Check with your vehicle manufacturer for hitch tongue weight limits.

Options





Fold-Able Model
Showing Foldaway Feature
FLC-0200-FD

Stow-Able Model Showing Stowaway Feature FLC-0200-SD

Showing Stowaway Feature FLC-2000

Model Specifications

Liberator Stow-Able and Fold-Able Models

Static Lifting Capacity | Tested to 300 lbs.

Recommended Maximum Lifting Capacity | 250 lbs.

Weight of Lift | 33 lbs. – 15 lbs. (Heaviest Component)

Vertical Lifting Height from Deck | 23" - 47" (Stow-Able), 49" (Fold-Able)

Maximum Lifting Height | 68"

Actuation | 12 VDC Motor Powered by Vehicle or Mobile Power Pack

Vehicle Receiver Hitch | Class II (1.25") or Class III (2")

Column Height | 32"

Boom Adjustment Range 27" to 35"

Receiver Base Clearance Beyond Hitch | 6" (Class II), 5" (Class III)

Liberator Plus

Static Lifting Capacity | Tested to 500 lbs.

Recommended Maximum Lifting Capacity | 400 lbs.

Weight of Lift | 41.5 lbs. - 19.5 lbs. (Heaviest Component)

Vertical Lift Height from Deck | 35"-47" (Stow-Able), 49" (Fold-Able)

Maximum Lifting Height | 68"

Actuation | 12 VDC Motor Powered by Vehicle

Column Height | 32"

Boom Adjustment Range | 27" to 35"

Base Length Adjustment | 15.5" to 26.5"

Model Numbers

Fold-Able w/ Deck BaseFLC-0200-FD	
Stow-Able w/ Deck BaseFLC-0200-SD	
Stow-Able w/ Class II Receiver BaseFLC-0200-SR	-2
Stow-Able w/ Class III Receiver BaseFLC-0200-SR	-3
Stow-Able w/ Class II Receiver Base & Mobile Power PackFLC-0200-BS	R2
Stow-Able w/ Class III Receiver Base & Mobile Power PackFLC-0200-BS	R3
Deck BaseFLC-0200-XD	
Class II Receiver BaseFLC-0200-XR	-2
Class III Receiver BaseFLC-0200-XR	-3
Liberator Plus w/ Heavy Duty Adjustable BaseFLC-2000-HD)